


QUICK START GUIDE

LCD CLOCK SET UP



Folding Table Stand



1: If you already have a Transmitter set up and running, you need to install 2 "C" batteries and set the channel.

2: Set to the exact same channel as the Transmitter by pressing CH button...

Wait for approximately 20 seconds. This should synchronize to the Transmitter time.

WAVE button is used to force the clock to receive a signal.

C/F button is to set Celsius, Fahrenheit or no display.

BATTERIES

If you don't have a Transmitter and need to set your clock manually, press SET button for at least 5 seconds to get into set mode. 12 HR will begin blinking. Press ▲ or ▼ to change between 12 HR and 24 HR display.

Press SET button again: 2015 will begin blinking. Press ▲ ▼ to set year.

Press SET button again: Month will begin blinking. Press ▲ ▼ to set Month. Next will be Date, Hour, Minute and Second. To finish, press SET button once more to get out of setting mode.