



QUICK START GUIDE

WHEN POWER AND GPS LIGHTS ARE ON, YOU'RE READY:

- * Your Transmitter should be Pre Programmed for your time zone.

- * If you see a different time zone, please follow Self Programming steps to change to your time zone.
- * If your area doesn't have Daylight Savings Time, please follow steps to cancel DST.
- * IF YOU DO NOT GET A GREEN LIGHT FROM THE GPS SIGNAL. YOU MAY INPUT THE TIME MANUALLY. THIS WILL CANCEL THE GPS ANTENNA AND INDICATE THE TIME YOU INPUT.

SELF PROGRAMMING STEPS:

1: Press and Hold Mode Button.

* CHANNEL SELECT

A: Press Set to choose a Channel (00-09)

2: PRESS MODE.

*UTC OFFSET

A: Press Set to Choose Time Zone

3: PRESS MODE.

*FORMAT

A: Press Set to Choose 12 or 24 Hour Clock

4: PRESS MODE.

*DAYLIGHT SAVINGS TIME

A: Press Set to Choose Yes / No

5: PRESS MODE.

* TIME

A: No (IF YES PRESS SET)

PRESS MODE.
*YEAR
A: Press Set To Choose Year

PRESS MODE.
*MONTH
A: Press Set to Choose Month

PRESS MODE.
*DAY
A: Press Set to Choose Day

PRESS MODE.
*HOUR
A: Press Set to Choose Hour

PRESS MODE.
*MINUTE
A: Press Set to Choose Minute

TRANSMITTER PROGRAMING

